



www.bowsbarn.com.au

Totem Pole Installation

1 - You will need a flat and level clear round area the size of the base plate (80cm) to install your Totem pole. We recommend that you dig this area down 5 to 10cm which will allow the base plate to be covered back over with dirt or grass once installed.



2 - Option A –

We recommend digging a hole for the anchor and using quick drying concrete to hold the anchor in place. Please use a level to ensure it is flat and level with the ground for the base plate. Allow to dry before continuing to step 3. (If you have a post hole digger this is much easier). The anchor is 50cm long.



2 - Option B - Use the 2 short screws to attach the chain rings to the anchor and thread the metal bar through these to allow you to turn the anchor clockwise until it is secured into the ground at the required height.



3 - Place the base plate on top of the anchor ensuring the bolt holes line up.



4 - Place the main shaft onto the base plate again ensuring the bolt holes line up and now install and tighten the 6 included bolts and washes.



5 - Installing the brushes. The suggested installation of the brushes is 2 down, 1 up, 1down, 2 up, 1 down 1 up and repeat until all the brush rings are installed.



6 - Attached the top plate using the 3 included bolts and washes to hold the brushes in place.



Installation - Concrete slab

1 - Place the main shaft onto the concrete slab to mark out and pre-drill the 6 required holes for the bolts.

2 - Place the main shaft onto the concrete slab and now install and tighten the 6 required bolts and washes into your pre-drilled holes.

3 - Installing the brushes. The suggested installation of the brushes is 2 down, 1 up, 1down, 2 up, 1 down 1 up and repeat until all the brush rings are installed.

4 - Attached the top plate using the 3 included screws and washes to hold the brushes in place.